



06 Mini-Me Worksheet

Prepare CADTERNs to draft a $\frac{1}{4}$ scale dressform by setting some temporary options in the Configure selection from main menu.

- Seam Allowance = 1.5 cm (5/8")
- Hem Allowance = 25 cm (10") Optional – to add base, if desired.
- Space between pieces = 0.

1. Sloper Definition folder

- Select Womenswear, Sheath, Precise Ease, Units (as you prefer).
- Insert name, height, bust, waist and hip measurements.

2. Measurements folder

- Copy Waist to Floor value in Waist to Knee box (for floor length).
- Accept default Ease Allotments (all = 0).

3. Sloper Preview folder

- Full length sheath appears with no space between pieces
- File/Save As/MistyK Dressform (or other name)
File/Print
 - o Print What? = Sloper Preview
 - o Sloper Preview Print Scale = Quarter Scale
- File/Print (Repeat for a second copy)

4. Assemble pattern

- Discard sleeve and collar pieces.
- Cut around perimeter of dressform.
- Join pattern tiles using clear tape.
- Close darts
 - o Cut along one side of each dart
 - o Clip mid-dart at waistline
- Join front to back at shoulder seams, matching seamlines.
- Join front to back along side seams, matching seamlines.